


## Edge E220 phone hardware features



### Poly Edge E220 Phone Hardware Feature Descriptions - Front

Reference Number	Feature	Description
1	LED bar	Provides call and phone status information.
2	Line keys	Select a phone line, view calls on a line, or quickly call a favorite contact.  Poly Edge E220 supports four keys.
3	Softkeys	Select context-sensitive keys that display along the bottom of the screen.
4	Pagination key	View additional line screens.
5	Back key	Return to the previous screen.

### Poly Edge E220 Phone Hardware Feature Descriptions - Front (continued)

Reference Number	Feature	Description
6	Navigation keys / Select key	Scroll through information or options displayed on the phone's screen or select a field of displayed data.
7	Home key	Display the <i>Home</i> screen from other screens or display the <i>Lines</i> and <i>Calls</i> screen from the <i>Home</i> screen.
8	Hold key	Hold an active call or resume a held call.
9	Forward/Transfer key	Forward or transfer an active call to a selected contact.
10	Volume keys	Adjust the volume of the handset, headset, speaker, and ringer.
11	Headset key	Place and receive calls through a headset.
12	Speakerphone key	Provides ringer and speakerphone audio output.
13	Mute key	Mute or unmute the microphone during an active call.
14	Dialpad	Enter numbers, letters, and special characters. Use the dialpad keys to select menu items that have index numbers.