


Poly Edge E450 Series phone hardware features



Poly Edge E450 Series Phone Hardware Descriptions

Reference Number	Feature	Feature Description
1	Surround lighting bar	Provides call and phone status information.
2	Line keys	Select a phone line, view calls on a line, or quickly call a favorite contact.
3	Softkeys	Select context-sensitive keys that display along the bottom of the screen.
4	Pagination key	View additional line screens.
5	Back key	Return to the previous screen.
6	Navigation keys / Select key	Scroll through information or options displayed on the phone's screen or select a field of displayed data.

Poly Edge E450 Series Phone Hardware Descriptions - Front (continued)

Reference Number	Feature	Feature Description
7	Home key	Display the <i>Home</i> screen from other screens or display the <i>Lines</i> and <i>Calls</i> screen from the <i>Home</i> screen.
8	Messages key	Access and manage instant and voice messages.
9	Hold key	Hold an active call or resume a held call.
10	Forward/Transfer key	Forward or transfer an active call to a selected contact.
11	Volume keys	Adjust the volume of the handset, headset, speaker, and ringer.
12	Dialpad	Enter numbers, letters, and special characters. Use the dialpad keys to select menu items that have index numbers.
13	Headset key	Place and receive calls through a headset.
14	Speakerphone key	Provides ringer and speakerphone audio output.
15	Mute key	Mute or unmute the microphone during an active call.
16	Secondary screen	Provides a lines screen in addition to the main screen.
17	Secondary screen line keys	Select a phone line, view calls on a line, or quickly call a favorite contact.
18	Secondary screen pagination keys	Navigate between pages on the secondary screen.