


# POLY ROVE 30

## Quick Function Guide



The following figure displays the hardware features on the Rove 30 wireless business media phone. The table lists each numbered feature shown in this figure.

### ROVE SERIES WIRELESS HANDSET HARDWARE FEATURE DESCRIPTIONS



**1. Call key** — Place a call, answer a call, or view recent calls.

**2. Navigation keys / Select key** — Scrolls through information or options displayed on the phone's screen. Selects a field of displayed data.

**3. Speakerphone key** — Place or answer a call using the wireless handset speakerphone, and switch between the speakerphone and the earpiece during a call.

**4. Mute key** — Mute or unmute the microphone during and active call.

**5. Volume keys** — Adjusts the volume of the handset, headset, speaker and ringer.

**6. Headset port** — Connect a headset to the phone.

**7. Multi function soft key.**

**8. Menu key** — Used to get to Transfer and Hold Functions while in a call.

**9. End Key** — Hang up or call or cancel the handset software update. Press and hold to power the handset on or off.

**10. Programmable Park Keys** — If lit in Green or Red, park keys are programmed on phone.

## VOICEMAIL

### Voicemail Setup

- To set up Voicemail, press and **hold the number 1 on keypad or Dial \*98**
- Contact EPB for your **temporary PIN number**.
- Follow the prompts to **change** your **PIN** and set up your greetings.

### Checking Voicemail

- Message light will **flash Green** if you have a Voicemail, and the **number of messages** will show up.
- To check Voicemail, **Press and hold the number 1** on keypad or **Dial \*98** and enter the pin.

## CALL FORWARDING

- **Dial \*72** plus the **10-digit forwarding number** and listen for beeps. This will only forward calls that call the cordless direct.
- **To remove** forwarding **Dial \*73** and listen for beeps. This will remove forwarding from the number associated with the cordless phone.

## TRANSFERRING A CALL

### Screened Transfer

- **While on a call** press the **Menu** key.
- **Press Transfer** and **select a contact or dial number** and press **Call**.
- When you're ready to **complete the call** press the **Center** key under the screen to complete the **Transfer**.
- If the **caller cannot take** the call, **Press** the **End Call** button.
- **Press Play** in the center under the screen.

### Blind Transfer

- While in a call **Press** the **Menu** key.
- Press **Blind Transfer** and **select a contact or dial a number** and press **Transfer** to complete.

## SET UP A 3-WAY CONFERENCE CALL

- While in a call press the **Menu** key.
- **Press Conference** and **select a contact or dial number** and press **Call**.
- When you are ready to join all the calls together, press the **Center** key under screen.
- To **end the Conference Call**, press the **End** key on phone. This will end the Conference call for all parties.

## CALL HOLDS

- While on a call, **Press** the **Center** button under the screen that looks like a pause button, or press the **Menu** key and select **Hold**.
- To pick up a call on hold **Press** the **Center** button under the screen that looks like a play button, or press the **Menu** key and press **Resume**.

## USING CALL PARK

- While on a call, **Press** the **L1 or L2** button above the number 1 and 2 button on the phone.
- The button should be **green** if no one is on that park key. The key will be **red** if there is a call on park.
- To retrieve a call from park, **Press L1 or L2** depending on which park the caller is on, and press a second time to retrieve call.

## MUTE CALL

- The **Mute** button on the left side of the phone will show a microphone with a line through it on the screen.
- **Press** the **Mute** button on the side of the phone again to Unmute the phone.

## CHECK CALL HISTORY

- **Press** the **Calls** button on the right side of the screen to **view call history**.
- Use the **navigation keys** to arrow over to the right to view **Received** calls, **Dialed** calls and **Missed** calls.
- Press the button under the three dots on the screen for options to **View Details, Save As Contact**, etc.
- Press the button under the word Back to **Return** to the idle screen.

